

76300 Arkham Asylum

- Installation requires a lot of patience and great observation that your LEGO bricks will come alive when you get this finished. The bricks with lighting as below, so make sure you're ready and let's get started.



Strategies for the Installation

This instruction divides three sections to complete the installation of the lighting set.

Section A: Check the type and quantity of components.

The quantity and type of components of each products are different and it needs to be carefully checked to make sure there do have enough material. The type of components is indicated by the label on the bag.

Section B: Test that each components is working properly.

Each components is made individually so it is necessary to test that each components is working properly to avoid the situation that the lighting does not work .

Section C: laying out components following the instruction.

Our material is very small but not fragile, just be reminded that don't to pull the wires too hard. For different people, there may be some installation steps that you can't understand. Please look at the previous and later installation step.

Section A: Check the type and quantity of components.

This set contains twelve bags labelled "1" "2" "3" "4" "5" "6" "7" "8" "9" "10" "11" "A01305 Power Supply", please make sure that the components in each bag are the same as shown in the pictures.





Please contact us immediately if there have any missing components.

Section B: Test that each components is working properly.


Take out the expansion board and usb power cable from "No. 4 bag " and the "A01305 Power Supply" .



It is worth reminding that our products are all customized. They have a unique way of connecting. The white plug on wire and the socket of the expansion board need to be connected together to transmit power.

Note that on one side of the white plug you can see two very small golden wires that should be connected to the two golden needles in socket of the expansion board.shown as blow.

Side-Mounted Expansion Board




All our connections between plug and socket are all the same as shown above. So for any such structure with plug and socket, please pay attention to the golden wire of the plug and the golden needle of the socket, they must be touched together.

The connection method between the usb power cord and expansion Boards is as follows:



The usb power cord can be powered by phone chargers, power banks,etc.

USB Connectors to Connect Devices



This instruction will use the power bank as power supply . The test structure is shown as follow. All lamp in this set will be tested by this structure.



When we test the "①" lighting fixtures, remove one of them and connect it to the socket. Turn on the portable power bank, and the light strip will light up normally, as shown in the figure below.




Test each lamp according to this method. It should be noted that after the test, the lamp must be returned to the corresponding bag to avoid confusion of types.



LED strip test:

Take out the led light bar, connect the usb power cable, turn on the mobile power supply, the light will be on normally, as shown in the figure below.



Attention that after the test is completed, each components should put back in the corresponding bag including the socket and the usb power cable.


Please contact us immediately if any components don't work.

Section C: laying out components following the instruction.

1





2





3



4. Take out a 15cm red common light bulb, place it between the protrusions of the building blocks, and then restore the red building blocks.




5. Look to the right, place the 5CM common light bulb - red between the protrusions of the building blocks, and then restore the red building blocks.





6



7





8







10. Take out a 15cm blue regular light bulb, place it between the protrusions of the building blocks, and then restore the blue building blocks.





11. Look to the right, place the 5cm regular light bulb - blue between the protrusions of the building blocks, and then restore the blue building blocks.





12





13





14



15




16




17




18




Breathing Light Module Function Introduce





19





20




21



22




23



24



25



26





27





28





29





30



31





32





33




34




35





36




37



38




39



40



41



42




43




44




45




46




47




48





Flame Module





①: Power input port (IN), connect to a power source, 5V DC.


②: Power output port (OUT), simulates the flickering frequency of flames.

PS: The flickering frequencies of the three power output ports (OUT) are independent and not synchronized.

50




51





52





53



54



55



56




57




58





59





60





61



62



63




64



65




66




67




68



69




Wireless Power Connectors





1. Wireless Power Connectors are divided into two parts.
2. The two parts need to be combined when connecting,
The positive pole is connected to the positive pole,
The negative pole is connected to the negative pole.





70




71





72



73




74




75




76



77





78




79




80




81




82



83




84




85





86




87



88





89




90



91





92




93





94




95




96





97





98





99





100




101



102



103




104





105





106




107




108




109





110





111





112



113





114



115



116





117



118



119




120




121




122




123



124



125




126



127




128




129



130




131



132





133



134



135




136



137





138




139




140




141




142





143




144




145




146




147




148




149





150




151




152





153



154




155




156



157




Wireless Power Connectors



1. Wireless Power Connectors are divided into two parts.
2. The two parts need to be combined when connecting,
The positive pole is connected to the positive pole,
The negative pole is connected to the negative pole.



158





159




160





161




162




163




164



165



166




167





168




169




170



171





172





173





174



175




176




177




178





Flame Module





①: Power input port (IN), connect to a power source, 5V DC.


②: Power output port (OUT), simulates the flickering frequency of flames.

PS: The flickering frequencies of the three power output ports (OUT) are independent and not synchronized.


180





181





182




183




184



185




186



187



188



Good job, you've done all the installation steps, power it up and enjoy your work.



The battery box can also power the set. If it is necessary to change the power supply , prepare three aaa batteries, install them in the battery box, turn on the switch on the battery box, remove the plug of the usb power cable from the socket of the expansion board,plug the plug of the battery box to the same socket in the expansion board to power the suit as well.

THANKS

Tips

If you encounter any installation problems please contact the seller, we will be happy to help you solve!