

INSTALLATION INSTRUCTIONS

21351 Disney Tim Burton's The Nightmare Before Christmas

 Installation requires a lot of patience and great observation that your LEGO bricks will come alive when you get this finished. The bricks with lighting as below, so make sure you're ready and let's get started.



Strategies for the Installation

This instruction divides three sections to complete the installation of the lighting set.

Section A: Check the type and quantity of components.

The quantity and type of components of each products are different and it needs to be carefully checked to make sure there do have enough material. The type of components is indicated by the label on the bag.

Section B: Test that each components is working properly.

Each components is made individually so it is necessary to test that each components is working properly to avoid the situation that the lighting does not work .

Section C: laying out components following the instruction.

Our material is very small but not fragile, just be reminded that don't to pull the wires too hard. For different people, there may be some installation steps that you can't understand. Please look at the previous and later installation step

Section A: Check the type and quantity of components.

There are 18 bags in this set. The name and quantities of specific components are as shown , please check carefully.

Label	Content	Quantity
A01003 Light-15CM Red	Light-15CM Red	3
A01010 Light-30CM Red	Light-30CM Red	1
A01017 Light-30CM Orange	Light-30CM Orange	1
A01019 Fast Flash-15CM Multi-Colour	Fast Flash-15CM Multi-Colour	1
A01023 High-Brightness Light 30CM-Warm White	High-Brightness Light 30CM-Warm White	1
A01024 High-Brightness light 15CM-Warm White	High-Brightness light 15CM-Warm White	4
01114 15cm 2x2 Double row light bar-Warm White	15cm 2x2 Double row light bar-Warm White	1
A012 Expansion Board	6 Socket Expansion Board	1
	6 Socket Expansion Board	3
	4 Socket Expansion Board	3
A01305 Power Supply	Power Supply	1
A01502 Connecting Cable 15CM	Connecting Cable 15CM	3
A01503 Connecting Cable 30CM	Connecting Cable 30CM	2
A01505 Connecting Cable 10CM	Connecting Cable 10CM	1
A02509 Light Strip-Green	Light Strip-Green	2
A02517 Light Strip-Blue	Light Strip-Blue	1
A02537 Light Strip-Blue	Light Strip-Blue	1
A1031 High-Brightness Light 15CM-Red	High-Brightness Light 15CM-Red	1
A1034 High-Brightness Light 30CM-Green	High-Brightness Light 30CM-Green	1
	Components	

Please contact us immediately if there have any missing components.


Section B: Test that each components is working properly.

We need a structure to test all lights, so take out the bag with label "USB Power Cord" and "Expansion Boards" as follows.



It is worth reminding that our products are all customized. They have a unique way of connecting. The white plug on wire and the socket of the expansion board need to be connected together to transmit power.

Note that on one side of the white plug you can see two very small golden wires that should be connected to the two golden needles in socket of the expansion board.shown as blow.



All our connections between plug and socket are all the same as shown above. So for any such structure with plug and socket, please pay attention to the golden wire of the plug and the golden needle of the socket, they must be touched together.

The connection method between the USB Power Cord and Expansion Boards is as follows:




This instruction will use the power bank as power supply . The test structure is shown as follow. All lamp in this set will be tested by this structure.



The USB Power Cord can be powered by phone chargers, power banks,etc.

USB connectors to connect devices



When we test "A01114 15cm 2x2 Double row light bar-Warm White" particles, Take out the bag labelled "A01114 15cm 2x2 Double row light bar-Warm White". Take out one of the light and connect it to the socket. Turn on the power bank, the light will turn on normally as shown below.



Test each lamp according to this method. It should be noted that after the test, the lamp must be returned to the corresponding bag to avoid confusion of types.



Section C: laying out components following the instruction.








4





Tips





The slit on the the plate round 1X1 are hand-made to avoid squeeze the wire and cause short circuit and abnormalheat during installation.













9




10



















16







19








22






24







26







28








31







33



34









37










40






42






44





46








48




49









52









55










58










61





63






65









68





70







72




73







75



76







78




79








82








84




85








88









91





93



94










98






100









103










106









109








112










115









118









121









124










127







130









133









136










139







142






144




145








148








151









154










157









160












164






166









169









172








174







Good job, you've done all the installation steps, power it up and enjoy your work.



The battery box can also power the set. If it is necessary to change the power supply, prepare three AAA batteries, install them in the battery box, turn on the switch on the battery box, remove the plug of the USB Power Cable from the socket of the expansion board, plug the plug of the battery box to the same socket in the expansion board to power the suit as well.

THANKS