

21357 Disney Pixar Luxo Jr. P90002

- Installation requires a lot of patience and great observation that your LEGO bricks will come alive when you get this finished. The bricks with lighting as below, so make sure you're ready and let's get started.



Strategies for the Installation

This instruction divides three sections to complete the installation of the lighting set.

Section A: Check the type and quantity of components.

The quantity and type of components of each products are different and it needs to be carefully checked to make sure there do have enough material. The type of components is indicated by the label on the bag.

Section B: Test that each components is working properly.

Each components is made individually so it is necessary to test that each components is working properly to avoid the situation that the lighting does not work .

Section C: laying out components following the instruction.

Our material is very small but not fragile, just be reminded that don't to pull the wires too hard. For different people, there may be some installation steps that you can't understand. Please look at the previous and later installation step.

Section A: Check the type and quantity of components.

This set contains three bags labelled "1" "2" "A01305 Power Supply", please make sure that the components in each bag are the same as shown in the pictures.




Please contact us immediately if there have any missing components.

Section B: Test that each components is working properly.

Take out the usb power cable and expansion board from "No. 2 bag " and the " A01305 Power Supply" .




The connection method between the usb power cable and expansion boards is as follows:



The usb power cable can be powered by phone chargers, power banks,etc.

USB Connectors to Connect Devices



This instruction will use the power bank as power supply . The test structure is shown as follow. All lamp in this set will be tested by this structure.



When we test the "①" lighting fixtures, remove one of them and connect it to the socket. Turn on the portable power bank, and the light strip will light up normally, as shown in the figure below.




Test each lamp according to this method. It should be noted that after the test, the lamp must be returned to the corresponding bag to avoid confusion of types.





Section C: laying out components following the instruction.



1



2




3



4




5



6



7



8




9




10



11



Optical Control Modules Function Introduce



TIPS:


1、The range of signal reception within 10cm of the vertical "signal receiver".

2、The frequency of objects passing through the "signal receiver" cannot be too high or the uncontrollable situations will occur.



3、The overall module is still working and consuming power even if the module is turned off. please turn off the power on the battery box or power bank If the light no longer be needed. please replace the power supply and try again If the light does not work for a period of time.

4、When the obstruction generate a re-
flected signal, the corresponding
module can be turned on or off.


12



13



14





Good job, you've done all the installation steps, power it up and enjoy your work.



The battery box can also power the set. If it is necessary to change the power supply , prepare three AAA batteries, install them in the battery box, turn on the switch on the battery box, remove the plug of the USB Power Cable from the socket of the expansion board,plug the plug of the battery box to the same socket in the expansion board to power the suit as well.

THANKS