


43197 Disney Frozen (Sound and Light Remote Control Version) GC33

Instructions for installing this kit:



Power supply: USB power cord (please bring your own power supply). The USB power cord can be energized through a USB battery box, a power bank, a mobile phone charger or a USB socket, and the normal use voltage is 3-5V.



USB connectors to connect devices



This product has 8 bags, and the battery box No.




Take out the accessories in the No. 5 and No. 7 bags.






Take out the expansion board and USB power cord separately.




Tear off the seal on the expansion board.




If there is a 2P interface in the package, please pay attention to the way the interface is used. The interface is small, please use it carefully: the = sign of the 2P interface is aligned with the = sign of the expansion board



Connect the USB power cord to the expansion board, paying attention to the orientation of the terminal ports.






In this article, the power bank is used for power supply, or the mobile phone charger can be used for power supply. The normal power supply is 5V.




Take out the lighting of the No. 1 bag.




Connect the lighting to the expansion board and pay attention to the connection method.




Turn on the power and test the lighting. If there is any abnormality, please contact us in time.




Pull off the lighting and put it back into the corresponding bag.



Take out the lighting of the No. 2 bag and test it in the same way.



After the test is normal, put the lighting back into the corresponding bag.



The lighting of other bags is tested in the same way.




After all the tests are completed, put the expansion board back into bag No. 5.




Note:



Please be careful when installing. The lamp wire is relatively slender and cannot be pressed on the raised position of the building block. It should pass along the gap, otherwise the lamp wire will be pinched.




Start Installation:



























































































































































































































































































































































































































































Note:



Please be careful when installing. The lamp wire is relatively slender and cannot be pressed on the raised position of the building block. It should pass along the gap, otherwise the lamp wire will be pinched.





































































































































































































The above are ideas and instructions provided by our designers. Please move on:

1: Do you have any suggestions about the material and quality of our products?

2: Do you have any suggestions on the installation instructions and the degree of difficulty of the installation?

3: If you have better installation method and ideas, please contact us in time.