

76178 Daily Bugle P24702

- P24702 is the unique code of lighting set, we use this to accurately identify the product you purchased and the corresponding manuals and services you need to obtain. Please make sure your product code is the same as the label on the back of the box shown “76178 P24702”.
- Installation requires a lot of patience and great observation that your LEGO bricks will come alive when you get this finished. The bricks with lighting as below, so make sure you're ready and let's get started.



Strategies for the Installation

This instruction divides three sections to complete the installation of the lighting set.

Section A: Check the type and quantity of components.

The quantity and type of components of each products are different and it needs to be carefully checked to make sure there do have enough material. The type of components is indicated by the label on the bag.

Section B: Test that each components is working properly.

Each components is made individually so it is necessary to test that each components is working properly to avoid the situation that the lighting does not work .

Section C: laying out components following the instruction.

Our material is very small but not fragile, just be reminded that don't to pull the wires too hard. For different people, there may be some installation steps that you can't understand. Please look at the previous and later installation step

Section A: Check the type and quantity of components.

There are 27 bags in this set. The name and quantities of specific components are as shown , please check carefully.

Label	Content	Quantity
Bit Lights-15CM-Warm White	Bit Lights-15CM-Warm White	1
Bit Lights-15CM-White	Bit Lights-15CM-White	2
Bit Lights-15CM-Red	Bit Lights-15CM-Red	5
Bit Lights-30CM-Red	Bit Lights-30CM-Red	2
Bit Lights-30CM-Warm White	Bit Lights-30CM-Warm White	2
Multi-Colour Lights 15CM	Multi-Colour Lights 15CM	1
Multi-Colour Lights 30CM	Multi-Colour Lights 30CM	1
Headlights-30CM-Warm White	Headlights-30CM-Warm White	2
Headlights-15CM-Warm White	Headlights-15CM-Warm White	7
LED Strip Lights-Blue	LED Strip Lights-Blue	1
LED Strip Lights-White	LED Strip Lights-White	4
LED Strip Lights-Warm White	LED Strip Lights-Warm White	1
Expansion Board	6 Socket Expansion Board	4
	8 Socket Expansion Board	2
	4 Socket Expansion Board	2
AA Battery Box	AA Battery Box	1
Flat Battery Pack	Flat Battery Pack	1
USB Power Cable	USB Power Cable-50CM	1
Connecting Cables-30CM	Connecting Cables-30CM	4
Connecting Cables-50CM	Connecting Cables-50CM	1
Connecting Cables-10CM	Connecting Cables-10CM	5
Connecting Cables-20CM	Connecting Cables-20CM	3
Flashing Bit Lights-30CM-Red	Flashing Bit Lights-30CM-Red	1
Flashing Bit Lights-15CM-Red	Flashing Bit Lights-15CM-Red	3
Multi-Colour Light String	Multi-Colour Light String	1
Light Strips-White-28	Light Strips-White-28	3
Light Strips-Red-28	Light Strips-Red-28	2
Remote Control Boards	Remote Control Boards	1
Parts package		

Please contact us immediately if there have any missing components.


Section B: Test that each components is working properly.

We need a structure to test all lights, so take out the bag with label “USB Power Cord”and “Expansion Boards”as follows.




It is worth reminding that our products are all customized. They have a unique way of connecting. The white plug on wire and the socket of the expansion board need to be connected together to transmit power.

Note that on one side of the white plug you can see two very small golden wires that should be connected to the two golden needles in socket of the expansion board.shown as blow.




All our connections between plug and socket are all the same as shown above. So for any such structure with plug and socket, please pay attention to the golden wire of the plug and the golden needle of the socket, they must be touched together.

The connection method between the USB Power Cord and Expansion Boards is as follows:



The USB Power Cord can be powered by phone chargers, power banks, etc.


USB connectors to connect devices



This instruction will use the power bank as power supply . The test structure is shown as follow. All lamp in this set will be tested by this structure.



when we test "Bit Lights-15CM-Red" particles,Take out the bag labelled "Bit Lights-15CM-Red".Take out one of the light and connect it to the socket. Turn on the power bank, the light will turn on normally as shown below.




Test each lamp according to this method. It should be noted that after the test, the lamp must be returned to the corresponding bag to avoid confusion of types.



The components needs to be tested in this set is 1*Bit Lights-15CM-Warm White,2*Bit Lights-15CM-White,5*Bit Lights-15CM-Red,2*Bit Lights-30CM-Red,2*Bit Lights-30CM-Warm White,1*Multi-Colour Lights 15CM,1*Multi-Colour Lights 30CM,2*Headlights-30CM-Warm White,7*Headlights-15CM-Warm White,1*LED Strip Lights-Blue,4*LED Strip Lights-White,1*LED Strip Lights-Warm White,1*Flashing Bit Lights-30CM-Red,3*Flashing Bit Lights-15CM-Red,1*Multi-Colour Light String,3*Light Strips-White-28,2*Light Strips-Red-28. Please contact us immediately if any components don't work.

Section C: laying out components following the instruction.

1




2




3




4



5



6




Tips

The plate without slit:

The plate without slit:

The squeeze causes the protective layer of the wire to be torn apart, the positive and negative wires touch together, and the set is short-circuited and the hot or wire is crushed, the wire to be disconnected and don't work.



The plate with slit:



The plate with slit:

The wire has enough space to avoid being squeezed and endowed with longer service life and more stable effect.





The slit on the the plate round 1X1 are hand-made to avoid squeeze the wire and cause short circuit and abnormalheat during installation.



7





8





9





10





11




12





13





14





15




16




17




18



19



20




Tips

The plate without slit:

The plate without slit:


The squeeze causes the protective layer of the wire to be torn apart, the positive and negative wires touch together, and the set is short-circuited and the hot wire is crushed, the wire to be disconnected and don't work.



The plate with slit:


The plate with slit:

The wire has enough space to avoid being squeezed and has a longer service life and more stable effect.




The slit on the the plate round 1X1 are hand-made to avoid squeeze the wire and cause short circuit and abnormal heat during installation.

21





22





23





24



25





26



27



28




29




30



31





32





33




34





35





36





37



38





39




40



41




42




43




44





45





46





47




48





49




50




51




52



53





54





55





56





57





58





59





60




61




62



63




64




65




66





67





68





69





70




71





72




73





74




75





76





77




78




79





80



81





82





83




84



85



86




87




88



89



90





91





92





93




94





95




96





97





98





99




100





101





102





103





104




105





106




107




108



109





110





111





112





113




114





115




116




117




118





119





120





121





122





123





124




125



126




127




128



129



130




131





132




133




134



135




136





137





138




139




140




141



142



143



144



Tips

The plate without slit:

The plate without slit:

The squeeze causes the protective layer of the wire to be torn apart, the positive and negative wires touch together, and the set is short-circuited and the hot or wire is crushed, the wire to be disconnected and don't work.



The plate with slit:


The plate with slit:

The wire has enough space to avoid being squeezed endowed with longer service life and more stable effect.




The slit on the the plate round 1X1 are hand-made to avoid squeeze the wire and cause short circuit and abnormal heat during installation.



145



146




147




148





149





150





151





152




153





154





155




156





157




158





159





160





161





162





163




164




165





166





167





168





169





170





171





172





173





174





175




176





177




178





179





180





181





182





183





184





185





186





187





188





189





190





191





192





193





194





195




196




197





198




199





200





201





202





203




204





205




206




207




208





209





210





211





212




213





214





215





216





217





218





219





220





221





222





223




224





225




226





227





228





229





230





231





232





233





234





235




236





237




238




239





240





241




242





243




244




245





246





247





248





249





250




251



252




253



254





255





256




257





258





259




260




261



262



263



Tips

The plate without slit:

The plate without slit:

The squeeze causes the protective layer of the wire to be torn apart, the positive and negative wires touch together, and the set is short-circuited and the hot or wire is crushed, the wire to be disconnected and don't work.



The plate with slit:


The plate with slit:

The wire has enough space to avoid being squeezed and is endowed with longer service life and more stable effect.




The slit on the the plate round 1X1 are hand-made to avoid squeeze the wire and cause short circuit and abnormal heat during installation.



264




265





266





267




268




269




270




271





272





273





274





275




276





277



278



279



Good job, you've done all the installation steps, power it up and enjoy your work.



The battery box can also power the set. If it is necessary to change the power supply , prepare three AA batteries, install them in the battery box, turn on the switch on the battery box, remove the plug of the USB Power Cable from the socket of the expansion board,plug the plug of the battery box to the same socket in the expansion board to power the suit as well.

THANKS