

# 76389 Hogwarts Chamber of Secrets P25802

- P25802 is the unique code of lighting set, we use this to accurately identify the product you purchased and the corresponding manuals and services you need to obtain. Please make sure your product code is the same as the label on the back of the box shown “76389 P25802”.
- Installation requires a lot of patience and great observation that your LEGO bricks will come alive when you get this finished. The bricks with lighting as below, so make sure you're ready and let's get started.



# Strategies for the Installation

This instruction divides three sections to complete the installation of the lighting set.

## **Section A:** Check the type and quantity of components.

The quantity and type of components of each products are different and it needs to be carefully checked to make sure there do have enough material. The type of components is indicated by the label on the bag.

## **Section B:** Test that each components is working properly.

Each components is made individually so it is necessary to test that each components is working properly to avoid the situation that the lighting does not work .

## **Section C:** laying out components following the instruction.

Our material is very small but not fragile, just be reminded that don't to pull the wires too hard. For different people, there may be some installation steps that you can't understand. Please look at the previous and later installation steps.

## Section A: Check the type and quantity of components.

There are 15 bags in this set. The name and quantities of specific components are as shown , please check carefully.

Label	Content	Quantity
Bit Lights-15CM-Warm White	Bit Lights-15CM-Warm White	11
Bit Lights-15CM-Red	Bit Lights-15CM-Red	1
Bit Lights-15CM-Green	Bit Lights-15CM-Green	5
Bit Lights-15CM-Blue	Bit Lights-15CM-Blue	1
Bit Lights-30CM-Green	Bit Lights-30CM-Green	2
Bit Lights-15CM-Pink	Bit Lights-15CM-Pink	1
Headlights-15CM-Warm White	Headlights-15CM-Warm White	4
Expansion Board	6 Socket Expansion Board	3
	8 Socket Expansion Board	1
	4 Socket Expansion Board	5
USB Power Cable	USB Power Cable-30CM	1
AA Battery Box	AA Battery Box	1
Connecting Cables-5CM	Connecting Cables-5CM	3
Connecting Cables-30CM	Connecting Cables-30CM	1
Connecting Cables-20CM	Connecting Cables-20CM	5
Flicker-Effects Board	Flicker-Effects Board	1
<b>Parts package</b>		

Please contact us immediately if there have any missing components.


## Section B: Test that each components is working properly.

We need a structure to test all lights, so take out the bag with label “USB Power Cord”and “Expansion Boards”as follows.



It is worth reminding that our products are all customized. They have a unique way of connecting. The white plug on wire and the socket of the expansion board need to be connected together to transmit power.


Note that on one side of the white plug you can see two very small golden wires that should be connected to the two golden needle in socket of the expansion board.shown as blow.






All our connections between plug and socket are all the same as shown above. So for any such structure with plug and socket, please pay attention to the golden wire of the plug and the golden needle of the socket, they must be touched together.

The connection method between the USB Power Cord and Expansion Boards is as follows:



The USB Power Cord can be powered by phone chargers, power banks, etc.


USB connectors to connect devices



**This instruction will use the power bank as power supply . The test structure is shown as follow. All lamp in this set will be tested by this structure.**



**when we test "Bit Lights-15CM-Warm White,Take out the bag labelled "Bit Lights-15CM-Warm White".Take out one of the light and connect it to the socket. Turn on the power bank, the light will turn on normally as shown below.**



Test each lamp according to this method. It should be noted that after the test, the lamp must be returned to the corresponding bag to avoid confusion of types.



The components needs to be tested in this set is 11\*Bit Lights-15CM-Warm White, 1\*Bit Lights-15CM-Red, 5\*Bit Lights-15CM-Green, 1\*Bit Lights-15CM-Blue, 2\*Bit Lights-30CM-Green, 1\*Bit Lights-15CM-Pink, 4\*Headlights-15CM-Warm White。  
Please contact us immediately if any components don't work。



**Section C:** laying out components following the instruction.



1



2




3








4




5




6




7



8





9







10



11





12








13



14




15









16



17




18









19



20




21









22



23





24






25



26



27






28



29



30





31



32



## Tips

The slit on the the plate round 1X1 are hand-made to avoid squeeze the wire and cause short circuit and abnormal heat during installation.

The plate without slit:

### **The plate without slit:**


The squeeze causes the protective layer of the wire to be torn apart, the positive and negative wires touch together, and the set is short-circuited and the hot or wire is crushed, the wire to be disconnected and don't work.




The plate with slit:

### **The plate with slit:**


The wire has enough space to avoid being squeezed endowed with longer service life and more stable effect.





33



34





35






36



37




38






39



40





41








42



43





44







45



46





47








48



49



50








51



52



53








54



55




56









57



58





59







60



61




62








63



64




65








66



67





68






69





70





71




72



73





74






75



76



77








78



79





80








81



82



83








84



85





86








87



88





89






90



91




92






93



94




95








96



97





98









99



100




101







102



103



104





## Tips

The slit on the the plate round 1X1 are hand-made to avoid squeeze the wire and cause short circuit and abnormal heat during installation.

The plate without slit:

### **The plate without slit:**


The squeeze causes the protective layer of the wire to be torn apart, the positive and negative wires touch together, and the set is short-circuited and the hot or wire is crushed, the wire to be disconnected and don't work.



The plate with slit:



### **The plate with slit:**

The wire has enough space to avoid being squeezed endowed with longer service life and more stable effect.









107



108





109









110



111





112









113



114





115








116



117





118









119



120





121








122



123





124









125



126





127








128



129





130








131



132




133







134



135




136






137



138





139








140



141



142





143



144





145









146



147



148






149



150




151







152



153





154








155



156





157





158



159




160







161



162




163








164



165




166







167



168



169






170



171





172







173



174





175







176



177





178







179



180




181







182



183





184





185



186





187









188



189




190








# 191



# 192





# 193






194



195




196





197



198





## Tips

The slit on the the plate round 1X1 are hand-made to avoid squeeze the wire and cause short circuit and abnormal heat during installation.

The plate without slit:

### **The plate without slit:**


The squeeze causes the protective layer of the wire to be torn apart, the positive and negative wires touch together, and the set is short-circuited and the hot or wire is crushed, the wire to be disconnected and don't work.



The plate with slit:


### **The plate with slit:**

The wire has enough space to avoid being squeezed endowed with longer service life and more stable effect.






201



202




203








204



205




206






207



208




209







210



211




212








213



214





215









216



217




218








219



220





221








222



223




224








225



226




227








228



229



230






231



232




233








234



235





236







237



238




239








240



241




242






245



246



247







**Good job, you've done all the installation steps, power it up and enjoy your work.**



**The battery box can also power the set. If it is necessary to change the power supply , prepare three AA batteries, install them in the battery box, turn on the switch on the battery box, remove the plug of the USB Power Cable from the socket of the expansion board,plug the plug of the battery box to the same socket in the expansion board to power the suit as well.**

**If everything is as excellent as expected, we'll be appreciate if a good review can be given.**

**THANKS**