

40532 Vintage Taxi LED lighting Kit (Classic Version)P31001

Installing Instructions:



Please follow below two parts to finish the installation of the lighting.

Step 1 : Test.

Step 2 : Installation.

Let us start.

Step 1 : Test.

The lighting materials are as follows, please confirm the quantity of lighting(this kit does not include batteries).


Quantity	Attribute name
3	Bit Lights-15CM-White
2	Bit Lights-15CM-Red
1	6-Port Expansion Boards
1	USB Power Cable-30CM
1	Flat Battery Pack
Other parts	

This set has a total of **6** bags. Take out the USB power cord and a **6**-Port Expansion Boards, and then tear off the seal of the expansion board. Coming with usb cable and battery box for choose, can be powered by power bank/wall charger or you can also use it with the battery.






擴充板
Expansion Boards






Available power supply devices for USB power cord.


USB connectors to connect devices



Please pay more attention and carefully using the connector for it is small. The “=” of the 2P interface is aligned with the “=” of the expansion board. The “=” on the expansion board refers to the two outside solder joints, not the two metal pins inside the jack.



Connect the USB power cord and expansion board together.




Connect the other side of the USB power cord to the mobile power supply (power prepare by yourself).




Remove the light bar from the bag and prepare for testing.



Connect the lighting to the expansion board then turn on the power switch. Testing whether the lighting is normal, if there is any problem, please contact us timely.



Unplug the lighting from the expansion board after finish testing and put it in back to the bag.




Put the okay lamp pellets back in the original packaging bag. To avoid the lighting kit can not work normally, please follow above method to test the other packs lighting kit before install it.



Attention:


Please be careful when installing since the lamp thread is slender. Cannot be pressed against the raised position of the building block. It should pass along the gap, otherwise the lamp wire will be pinched.





Step 2 : Installation


start installation:












Friendly tips

The small round pellets in the parts package are designed with openings. After manual processing, the cut-out gap is about 1mm wide and 2mm deep.



No opening:






Opening pieces:



Need to install the lamp thread through the gap on the building block.













Attention:


Please be careful when installing since the lamp thread is slender. Cannot be pressed against the raised position of the building block. It should pass along the gap, otherwise the lamp wire will be pinched.











Friendly tips

The small round pellets in the parts package are designed with openings. After manual processing, the cut-out gap is about 1mm wide and 2mm deep.



No opening:







Opening pieces:






Need to install the lamp thread through the gap on the building block.

































Complete install and plug in the power to try it.



Above creative ideas and instructions are provide by our designers.

But we treasure your suggestions or opinions on below.

- 1. Parts materials, product quality,others about our company?**
- 2. Installation instructions of this product and the difficulty during install?**
- 3. If you encounter any problems during using our product, please contact us in time.**