


# 75329 Death Star Trench Run Diorama P34402

- P34402 is the unique code of lighting set, we use this to accurately identify the product you purchased and the corresponding manuals and services you need to obtain. Please make sure your product code is the same as the label on the back of the box shown “75329 P34402”.
- Installation requires a lot of patience and great observation that your LEGO bricks will come alive when you get this finished. The bricks with lighting as below, so make sure you're ready and let's get started.



# Strategies for the Installation

This instruction divides three sections to complete the installation of the lighting set.

## **Section A:** Check the type and quantity of components.

The quantity and type of components of each products are different and it needs to be carefully checked to make sure there do have enough material.

The type of components is indicated by the label on the bag.

## **Section B:** Test that each components is working properly.

Each components is made individually so it is necessary to test that each components is working properly to avoid the situation that the lighting does not work .

## **Section C:** laying out components following the instruction.

Our material is very small but not fragile, just be reminded that don't to pull the wires too hard. For different people, there may be some installation steps that you can't understand. Please look at the previous and later installation step

## Section A: Check the type and quantity of components.

There are 13 bags in this set. The name and quantities of specific components are as shown , please check carefully.

Label	Content	Quantity
Light-30CM Green	Light-30CM Green	2
Light-30CM Pink	Light-30CM Pink	1
High-Brightness Light 30CM-Warm White	High-Brightness Light 30CM-Warm White	1
Light-15CM Cyan	Light-15CM Cyan	2
Expansion Board	6 Socket Expansion Board	1
	12 Socket Expansion Board	1
Power Supply	Power Supply	1
Connecting Cable 5CM	Connecting Cable 5CM	1
Connecting Cable 15CM	Connecting Cable 15CM	1
Flash Light-30CM Red	Flash Light-30CM Red	2
Light Strip-Warm White	Light Strip-Warm White	1
Sound Control Module	Sound Control Module	1
High-Brightness Light 15CM-Green	High-Brightness Light 15CM-Green	3
Components		

Please contact us immediately if there have any missing components.


## Section B: Test that each components is working properly.

We need a structure to test all lights, so take out the bag with label “USB Power Cord” and “Expansion Boards” as follows.




It is worth reminding that our products are all customized. They have a unique way of connecting. The white plug on wire and the socket of the expansion board need to be connected together to transmit power.

Note that on one side of the white plug you can see two very small golden wires that should be connected to the two golden needles in socket of the expansion board. shown as blow.




All our connections between plug and socket are all the same as shown above. So for any such structure with plug and socket, please pay attention to the golden wire of the plug and the golden needle of the socket, they must be touched together.

The connection method between the USB Power Cord and Expansion Boards is as follows:



The USB Power Cord can be powered by phone chargers, power banks, etc.


### USB connectors to connect devices



**This instruction will use the power bank as power supply . The test structure is shown as follow. All lamp in this set will be tested by this structure.**



**When we test " High-Brightness Light 30CM-Warm White" particles,Take out the bag labelled " High-Brightness Light 30CM-Warm White".Take out one of the light and connect it to the socket. Turn on the power bank, the light will turn on normally as shown below.**



**Test each lamp according to this method. It should be noted that after the test, the lamp must be returned to the corresponding bag to avoid confusion of types.**




**The components needs to be tested in this set is 2\* Light-30CM Green,1\* Light-30CM Pink,2\* Light-15CM Cyan ,2\* Flash Light-30CM Red,1\* Light Strip-Warm White,3\* High-Brightness Light 15CM-Green.**



**Please contact us immediately if any components don't work.**

## Section C: laying out components following the instruction.



1



2





3







4




5





6





7




8





9




10





11





12





13





14



15





16



17



18



# Tips

The plate without slit:

## The plate without slit:

The squeeze causes the protective layer of the wire to be torn apart, the positive and negative wires touch together, and the set is short-circuited and the hot wire is crushed, the wire to be disconnected and don't work.



The plate with slit:



## The plate with slit:

The wire has enough space to avoid being squeezed and has longer service life and more stable effect.




The slit on the the plate round 1X1 are hand-made to avoid squeeze the wire and cause short circuit and abnormal heat during installation.


## 19




## 20



# 21



# 22



## Tips

The plate without slit:

### The plate without slit:

The squeeze causes the protective layer of the wire to be torn apart, the positive and negative wires touch together, and the set is short-circuited and the hot or wire is crushed, the wire to be disconnected and don't work.



The plate with slit:


### The plate with slit:

The wire has enough space to avoid being squeezed endowed with longer service life and more stable effect.





The slit on the the plate round 1X1 are hand-made to avoid squeeze the wire and cause short circuit and abnormal heat during installation.



23



24





25








26





27





28





29




30




31





32




33





34





35



36



37




38



39



40



# Tips

The plate without slit:

## The plate without slit:

The squeeze causes the protective layer of the wire to be torn apart, the positive and negative wires touch together, and the set is short-circuited and the hot or wire is crushed, the wire to be disconnected and don't work.



The plate with slit:


## The plate with slit:

The wire has enough space to avoid being squeezed and is endowed with longer service life and more stable effect.





The slit on the the plate round 1X1 are hand-made to avoid squeeze the wire and cause short circuit and abnormal heat during installation.


# 41





42





43





44





45



46




47








48





49



50





51




52





53




54





55



56




# 57



# 58



## Sound Control Module



Module sensitivity adjuster. There are three gears, **1,2, and 3**. The received decibels are **25dB, 50dB, 90dB**.

In a noisy environment, using the 1st gear, the lights will always be on and off. At this time, you need to increase the gear to 2 or 3 gears to work normally. In a quiet environment, Gear 3 will be difficult to trigger. It is recommended to use gear 1 or 2.



**Please replace the battery box with a power bank as the power supply if the light does not work properly after a period of time.**

**The module consumes a lot of power and the battery with normal capacity can only be used for three days or even less, the module is still working even if the light is off, so Please turnoff the switch on the battery compartment if the light is no longer needed.**


59




60




61



# 62



Good job, you've done all the installation steps, power it up and enjoy your work.



The battery box can also power the set. If it is necessary to change the power supply , prepare three AAA batteries, install them in the battery box, turn on the switch on the battery box, remove the plug of the USB Power Cable from the socket of the expansion board,plug the plug of the battery box to the same socket in the expansion board to power the suit as well.

**THANKS**